

Factory Reset iConnect612

A Factory Reset maybe required if configuration details in the router are changed and you lose the ability to configure the unit via the web interface. In order to restore functionality, you may need to reset the unit to factory defaults.

Restoring the 612 to Factory Defaults will remove the current configuration and set all values to the factory default. The PPP login and password will be removed, therefore ensure you have this information available to re-enter. All customisation (ie. port forwarding, access control) will be removed. The unit will default to the following setting:

IP: 192.168.1.254
Login: root
Password: ØP3N

To Reset the iConnect612 Factory Defaults:

- Ensure that the iConnect612 has been powered on for a minimum of 30 seconds and the DSL light is either on or flashing.
- Ensure the Ethernet and the phone cables are connected. If this is not possible you will not see the LED's flash during the reset.
- Use a blunt implement, such paperclip to press the reset button at the back of the unit for approximately 10 seconds until the power LED turns red.



NOTE:

Do NOT power down the Connect612 whilst in the process of resetting
