

Caution


1. Do not insert the wireless LAN adapter into your computer until the procedures in “Install the Driver & Utility” have been performed.
2. This quick Installation is meant to help you install the product quickly and easily. For detailed instructions on installation, please refer to the User Manual.
- 3.

1**Install the Driver & Utility**

1. Exit all Windows programs. Insert the included CD-ROM into your computer. The CD-ROM will run automatically.
2. When the Main Menu screen appears, click “**Driver & Utility Installation**” to continue.
3. When the welcome screen appears, click **Next** to start installation.



4. The system will automatically direct to the destination folder, just click **Next** to continue.

**5**

Click Finish to complete the software installation.

**2****Install the Device**

1. Locate your USB host and insert the USB Adapter.
2. Once the device has been inserted to your computer, Windows will detect the new hardware and complete the hardware installation automatically, just double-click the utility icon on the desktop to configure the utility.
3. When finished, you can check if the device is properly installed and enabled.
 - a. Go to **Start** → **Settings** → **Control Panel** → **System** (→**Hardware**) → **Device Manager**.
 - b. Expand the **Network adapters** category
 - c. If the **802.11b+g USB Wireless LAN Adapter** is listed, the device is well-installed and ready to use.

